

Colocando o Segundo Cartão SIMM Flash

Router#show flash

System flash directory, partition 1:

File Length Name/status

1 7987220 c2500-j-l.112-16

[7987284 bytes used, 401324 available, 8388608 total]

8192K bytes of processor board System flash (Read ONLY)

System flash directory, partition 2:

File Length Name/status

1 7987220 c2500-j-l.112-16

[7987284 bytes used, 401324 available, 8388608 total]

8192K bytes of processor board System flash (Read/Write)

Router(config)#partition flash 1 16

%Error: Erasure of partition 2 required.

Router(config)#^Z

Router#

=====

Router#erase flash

Partition	Size	Used	Free	Bank-Size	State	Copy Mode
1	8192K	7800K	391K	8192K	Read ONLY	RXBOOT-FLH
2	8192K	7800K	391K	8192K	Read/Write	Direct

System flash directory, partition 2:

File Length Name/status

1 7987220 c2500-j-l.112-16

[7987284 bytes used, 401324 available, 8388608 total]

Erase flash device, partition 2? [confirm]

Are you sure? [yes/no]: y

Erasing device... eeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeee ...erased

Router#sh flash

System flash directory, partition 1:

File Length Name/status

1 7987220 c2500-j-l.112-16

[7987284 bytes used, 401324 available, 8388608 total]

8192K bytes of processor board System flash (Read ONLY)

System flash directory, partition 2:

No files in System flash

[0 bytes used, 8388608 available, 8388608 total]

8192K bytes of processor board System flash (Read/Write)

=====

Router#configure terminal

Router(config)#partition flash ?

<1-8> Number of partitions in device

Router(config)#partition flash 1 ?

<1-64> Size of partition 1

<cr>

Router(config)#partition flash 1 16

Router(config)#^Z

Router#

Router#sh flash

System flash directory:

File Length Name/status

1 7987220 c2500-j-l.112-16

[7987284 bytes used, 8789932 available, 16777216 total]

16384K bytes of processor board System flash (Read ONLY)

